



## FALCON RIDGE

2515 Bypass Rd. Flemingsburg, KY 41041  
606-845-7439

**Instructions for Installation and Care of**  
**Mahindra Roxor**  
**Soft Top Cap**  
MAH-ROXOR-TC01

**Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.**

1. Be sure to read these instructions thoroughly before opening and installing the enclosure. The installation is best done when the temperature is 70 degrees F. or warmer. The temperature affects the adhesive Velcro, if conditions prevent installing in warmer weather it helps to store the adhesive Velcro at room temperature prior to installation.
2. Check over the parts included in the carton with the parts list shown below:

Adhesive Velcro Hook Strips:

“ “ “ “	4 each-----6”
Webbing Straps with Velcro	2 each-----60”
	2 each-----25”

1. The last item to install is the Top Cap. You have been supplied with 4 straps with double-sided Velcro sewn to one end. Take the 6” adhesive Velcro strips and wrap them around the bars at the following locations.
2. In the front wrap the bar just under the windshield clamp with the 6” adhesive Velcro. Then wrap the double-sided Velcro sewn to the end of the short strap around the adhesive Velcro as tight as you can get it. Then run the strap through the buckle in the front corner of the Top Cap. Do not pull it tight yet, just pull it in place. See photo below.



3. The rear of the Top Cap is held in place using the straps that have double-sided Velcro sewn in one end. Take the 6" adhesive Velcro strips and wrap them around the roll cage at the bottom rear of the roll cage just below where the sides and rear panels come together. Now take the end of the strap with the Velcro and wrap it around the bar and Velcro as tight as possible. Then take the other end of the strap and run it through the loop, pulling it tight. The photo below shows what it should look like.



4. Once all the straps are in place run them through the buckles. Pull them tight making sure the top is centered and the side seams line up correctly along the roll cage. The diagram below shows how to lace the webbing through the buckle.

